


## JCB-HT-PRO-DIAL 700

### 700 LUMEN MULTI-FUNCTIONAL RECHARGEABLE HEAD TORCH



#### 5 IN 1 FUNCTIONS

- **5 light settings:**
  1. Cool white 300 lumen
  2. Warm white 300 lumen
  3. Wide angle flood 450 lumen
  4. Red wide angle 20 lumen
  5. Turbo 700 lumen
- Stepless dimming in all modes
- Wave sensor on/off in all mode



#### DIMENSIONS



## PRODUCT DESCRIPTION

5 in 1 head torch with rotary control switch for the different light functions and dimming. Separate switch activates a wave sensor so the light can be turned on/off with your hand

4 brightness levels 700/400/300/18 lumens with wide flood beam

Battery status indicator

Latest polymer Li-ion battery technology

IP44 dust and waterproof

USB -C charging

## SPECIFICATION

Charging:	USB C
Battery:	Built-in 1200mAh Li-ion
Charge Time:	2.5h
Runtime:	1.5 to 30hr runtime (dependent on output)
Brightness:	700/400/300/18 lumens

## BATTERY TREATMENT / CHARGING

Recharge when the indicator turns red

Fully charged when green indicator stops flashing

Do not leave the battery fully discharged

## OPERATION

### DIAL POSITION



## **OPERATION (CONTINUED)**

### **HEAD TORCH MODE**

1. Place the head torch on your head and adjust the strap for comfort.
2. Rotate the on/off switch to the desired setting and press the inner button until the desired brightness is reached. To enter the turbo mode double press the inner button at anytime.

- Cool White CCT 6500K
- Warm White CCT 3000K
- COB Flood White CCT 6500K
- COB Flood RED

3. To switch off turn the on / off switch counterclockwise. The green led indicator light adjacent to the power button will also switch off. Light shows green for charged and red for low battery.

### **DIMMING MODE**

With the lamp switched on, long press the side button to activate dimming function (dims the current lighting mode).

### **FLASHING MODE**

Works with Cold White spotlight - single-click the side button to enter the flashing mode. When the head torch is on Flood RED, pressing the central button changes the solid light to a flashing one.

### **WAVE / MOTION SENSOR MODE**

1. For ease of use, or simply if the user has oily or dirty hands the PRODIAL 700 has been design with a none contact wave/motion sensor on / off switch.
2. To activate the wave motion sensor mode, press the motion mode button on the top of the head torch.
3. Passing / waving your hand within 3cm of the light front will automatically toggle the light from ON to OFF or OFF to ON. Movement can be up and down or towards the light to be detected by the sensors.
4. To switch off this mode either press the button on the top of the head torch again, to turn off activating the light on permanently, or press the wave / motion button to switch all modes off.



## SAFETY NOTICE

Prior to use carry out the necessary risk assessment considering the people who could be at risk, the level of risk and the precautions required to control the risk.

### GENERAL

Ensure the worklight is correctly charged before initial use

DO NOT cover or block the lens during use

DO NOT shine the product directly into the eyes of people or animals

DO NOT allow children to use the worklight

DO NOT handle or move the worklight while it is being charged

DO NOT use the worklight if you suspect it is damaged

DO NOT place the product in or near naked flames

DO NOT open the equipment or touch any of the internal parts

DO NOT open the battery pack

DO ensure the worklight is unplugged and allow to cool before attempting cleaning and maintenance

### BATTERY

**WARNING!** To reduce the risk of fire or burns:

DO NOT attempt to open, disassemble, modify or service the battery

DO NOT expose to temperatures below 10°C or above 40°C

DO NOT crush, puncture, short external contacts or dispose of in fire or water

DO NOT dispose of with regular waste - dispose of the old batteries in

accordance with local authority battery regulations

DO NOT cover the battery while charging

Ensure the charger is switched off and disconnected from the worklight before attempting to open the lamp unit

If the electrolyte in the cells comes into contact with the skin, wash thoroughly with soap and water

If the electrolyte in the cells comes into contact with the eyes, rinse thoroughly with cold water and seek immediate medical attention

The worklight should be turned off during charging to prolong battery life

## SAFETY NOTICE

### ELECTRICAL

**WARNING!** It is the user's responsibility to read, understand and comply with the following electrical instructions:

Ensure the risk of electrical shock is minimised by the installation of appropriate safety devices

Inspect the charger cable and connection for wear and damage to ensure the items are safe before connecting to the mains power supply

DO NOT use if worn or damaged

Check cables are always protected against short circuit and overload

DO NOT place the connector into any area of the worklight except the correct outlet socket

DO NOT use the cable to charge or power any other electrical items

DO NOT wet the cable or use in wet or damp conditions (indoor use only)

### MAINTENANCE & STORAGE

Keep the worklight clean from dirt and grease using a damp cloth

DO NOT submerge in water

DO NOT clean the worklight with solvents

DO check the product for damage before each use

If the product is not used for a long time, the battery will go into over discharge protection. To re-activate the battery, charge three or four times for 30 seconds until the indicator light comes on. Then fully charge the battery as normal.



## GUARANTEE

This product is guaranteed against manufacturing defects for a period of 3 years from the date of purchase.

Repair or replacement of products will be undertaken providing that:

- The product has been subject to fair wear and tear only
- The product has not been subject to accidental or cosmetic damage
- The product has not been misused and has been used only in accordance with the instruction manual provided
- The product has not been subject to insufficient servicing and maintenance
- The product has not been subject to any abnormal environmental conditions or inappropriate operating conditions
- Repairs have not been attempted by an unauthorised person and no modifications have been made to the product

The guarantee excludes the following (where relevant):

- Components normally subject to wear and tear
- Batteries and chargers

Your statutory rights are not affected.

We reserve the right to alter specifications without prior notice

**WE WILL NOT BE LIABLE FOR ANY INJURIES OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT**

## GENERAL WARNINGS & DISPOSAL

This product has been marked with a symbol relating to removing electric and electronic waste. The product should not be discarded with household waste but must be returned to a collection system which conforms to the European Directive 2012/19/EU. It will then be recycled or dismantled in order to reduce the impact on the environment. Electric and electronic equipment can be hazardous for the environment and for human health since they contain hazardous substances.



[www.jcbworklights.com](http://www.jcbworklights.com) | [sales@jcbworklights.com](mailto:sales@jcbworklights.com)

JCB Lighting is used under licence by Property Perspective Ltd

